RUBBER-LIKE RESIN Flexible 3D Printer Photopolymer

TECHNICAL DATASHEET

Table of Contents

- 1. Cover Page
- 2. Product Overview
- 3. Mechanical Properties
- 4. Other/Liquid Properties
- 5. Workflow Procedures
- 6. Glossary of Key Terms
- 7. Disclaimer

Monocure3D[®]

Monocure 3D Pty Ltd Unit 16 / 364 Park Road Regents Park NSW 2143 AUSTRALIA +61 (0) 2 9738 5340 support@monocure3d.com.au monocure3d.com.au

PRODUCT DESCRIPTION

Monocure3D presents Rubber-like Resin. Finally, a true rubber-like UV-cured photopolymer resin, taking flexible 3D printing material to the next level! Designed for a use in all MSLA desktop 3D printers, our Rubber-Like resin has a unique composition closely resembles rubber in elasticity after post-processing with the ability to stretch to over 166% and return to its original shape.

NAME: RUBBER-LIKE SKU(s): M/RUB-4049BK

Available Colour(s): Black

Suitable Models: Model Tyres | Grips & Bands | Meshes | Sleeves & Joints | Washers | Gaskets Seals | Grommets Hoses and Tubing | Bumpers | Wearables |

Monocure3D[®]

A rubber-like UV-cured photopolymer resin. Designed for a use in all MSLA desktop 3D printers, Rubber-Like resin has a unique composition closely resembles rubber in elasticity after post-processing.

Features and Benefits

- Robust Properties: Exhibits impressive elongation, and rebound rate, making it ideal for functional prototypes and parts requiring flexibility, stretchability and durability.
- Balanced Adhesion: The resin maintains a perfect balance with adhesion to the build plate, ensuring easy removal without compromising print integrity.
- High Resolution: Rubber-like boasts high-resolution output and minimal shrinkage, or splitting.
- Authentic Rubber Feel: Offers an authentic rubber-like feel, opening a realm of applications in various industries.
- Optimized Post-Cure: Following the post-processing guide below will enhance the tactile experience and usability.
- Tuning to Perfection: To achieve optimal results, we recommend following the MonoSteps below. If you need further assistance, please contact us through our support page or you can sign up to our Facebook Users Group to get help from our

TECHNICAL DATASHEET

RUBBER-LIKE RESIN Flexible 3D Printer Photopolymer

Applications

Monocure3Ds Rubber-like resin can cater to diverse industrial and hobbyist needs.

- Model Tyres
- Grips & Bands
- Meshes
- Sleeves & Joints
- Washer, Gaskets and Seals
- Dampeners and Shock Absorbers
- Grommets and Bumpers
- Hoses and Tubing

UNICAL[™] CALIBRATION MODEL

Using a calibration model efficiently adjusts a 3D resin printer to work seamlessly with our Rubber-Like resin. Proper dialling-in ensures the harmonious operation between the printer and resin, yielding models of exceptional precision.



Download STL file and full instructions by scanning the QR code.



/product-category/3d-models/calibration-models/

TDS-4015 Revision: 04 Dec 2023



www.monocure3d.com.au

Monocure3D



Monocure3D Rubber-like Resin

Technical Specifications

- 1. Appearance: Flowing liquid
- 2. Density: 1.00 ~ 1.05 g/cm3
- 3. Viscosity: 1400 ~ 1800 cps at 25°C
- 4. Hardness: 65 ~ 67A (Shore A, ASTM D2240)
- 5. Elongation: 166.9% (ASTM D638)
- 6. Tensile Strength: 1.92 Mpa (ASTM D638)
- 7. Tensile Modulus: 2 Mpa (ASTM D638)
- 8. Resilience: 15% (ASTM D2632-15)
- 9. Glass Transition Temperature: -10°C (DSC)

Monocure3D's PRO Rubber-like resin is a transformative solution, adding flexibility and durability to your 3D printing capabilities.



Monocure3D[®]

RUBBER-LIKE RESIN Flexible 3D Printer Photopolymer

WORKFLOW PROCEDURES

When using 3rd party materials, it is essential to remember that most 3D printers are unique and require setting up before first-time use. We recommend that you dial-in new printers and resins using one of our handy calibration models that you can download from here: https://monocure3d.com.au/product-category/3d-models/calibration-models/

PRINTER SETTINGS

The following example settings are with consideration for monochrome LCD MSLA 3D printers employing a 405nm light source. For more information about all our materials and most popular 3D printer models, please refer to the official settings page at: /monocure3d.com.au/printers/

Shake the RUBBER-LIKE bottle thoroughly before use and open it in a UV-protected environment. Pour into the printer's vat, allow bubbles to settle, and ensure the temperature is between 18°C and 35°C for optimal printing.

Layer Thickness: 50µm Base layer Duration: 30(sec) No. Base Layers: 4 Normal Layer Exposure: 3(sec)

MonoSteps to Success

1. **Preparation of Resin:** Shake the resin container well to ensure uniformity. Carefully remove the protective seal. Pour the resin into the printer's vat allow bubbles to dissipate before proceeding.

2. Calibration Test: Print a calibration model to ensure the printer is accurately dialled in for the new resin. This helps in fine-tuning the settings for optimal printing success.

3. **Model Placement and Support Structure:** Given the elastic nature of PRO Rubber-like resin, proper model placement and support structure are vital. Set the supports to be heavy and dense, ensuring strong contact points. Whenever feasible, place models directly on the build plate to enhance print success.

4. **Design Considerations for Hollow Parts:** For hollow parts or designs prone to creating suction, create 1-2mm holes near the build plate in the model using your slicer software. This allows air to escape during printing and facilitates resin drainage from hollow sections post-printing.



Monocure3D[®]



MonoSteps to Success (con't)

5. Lift heights and speeds: Since the material is prone to stretching during the printing process, we recommend you increase the build plate lift heights and reduce your print speeds. This will aid in the printing process and reduce the failure rate considerably.

6. **Post-Printing Cleaning:** Start with a pre-wash using ResinAway or Isopropyl Alcohol to remove uncured resin. Follow up with a thorough cleaning in an ultrasonic cleaner or wash unit. Dry the print completely using compressed air or a lint-free cloth. It's important to avoid water contact until post-curing is complete.

7. **UV Post-Curing:** Expose the print to UV light in a curing unit, ideally with a wavelength range of 365-405nm. A 60-minute exposure is recommended, although larger parts may require a longer duration.

8. **Heat Curing for Enhanced Properties:** For optimal mechanical properties, heat curing is recommended. This involves curing the part at 70°C for 60 to 120 minutes.

9. **Final Inspection and Finishing:** After curing, inspect the print for any imperfections or uncured resin. If necessary, perform light sanding or trimming to refine the surface or remove any support marks.

10. **Storage of Unused Resin:** If there is unused resin in the vat, filter it and store it in an airtight container. Keep it away from direct sunlight and in a cool, dry place.

11. **Maintenance of Printer and Vat:** Regularly clean and maintain your printer and vat to ensure consistent printing quality. Check for any resin spills or debris and clean accordingly with ResinAway Ezy Wipes.



Monocure3D



Glossary of Key Terms and Concepts

- 1. 3D Print: The process of creating a three-dimensional object from a digital file by layering material in successive layers.
- 2. Base Layer: The first layers in a 3D printed object that adheres to the build plate.
- 3. Calibration Model: A specific 3D design used to adjust and test the accuracy of a 3D printer.
- **4. Curing Interface:** The platform on which the 3D print is formed and solidified.
- 5. Elongation at Break: The measure of a material's ductility represented as a percentage elongation of area during rupture.
- 6. Elephant's Foot: A phenomenon where the base layer of a print expands outwards, creating a bulged, widened base.
- 7. Extreme Tensile Strength: A high level of resistance to breakage under tension.
- 8. Green Strength: The strength of the uncured or unfinished 3D printed resin object.
- 9. Heat Deflection Temperature (HDT): The temperature at which a polymer or plastic sample deforms under a specified load.
- 10. IZOD Impact Strength Test: A standard method of determining the impact resistance of materials.
- 11. Layer Thickness: The height of each individual layer of a 3D printed object, usually measured in microns (μm).
- 12. Liquid Absorption Test: Measures a material's ability to absorb liquid over a given period of time.
- 13. Monochrome LCD MSLA: A 3D printer that uses a monochrome) LCD to cure a vat of light-sensitive resin layer by layer.
- 14. Post-Curing: The process of exposing a 3D printed part to a light source after printing to further cure and harden the resin.
- **15. Post-Processing:** The final steps taken after a 3D print is complete to achieve the desired finish.
- 16. RESINAWAY®: A cleaning solution used to remove uncured resin from the surface of a 3D print.
- 17. Resin: The light-sensitive liquid material that is solidified layer by layer in a resin-based 3D printer to create an object.
- **18. Shore D Hardness:** This is a measure of the hardness of a material, typically a plastic or rubber.
- **19. Surface Scratch Test:** Measures the amount of scuff or abrasion that is caused by two surfaces rubbing together.
- **20.** Supports: Temporary structures printed along with a 3D print that hold overhanging parts of the print in place until it's cured.
- 21. TENSILE™: The product name for an industrial type of 3D printing resin produced by Monocure 3D.
- 22. Tensile Strength: The maximum stress that a material can withstand while being pulled before failing or breaking.
- **23. UV Light Source:** A type of light used in the post-curing process of 3D printed resin parts.
- **24. Young's Modulus:** Young's Modulus is a mechanical property that measures the stiffness of a material.



Monocure3D^e

RUBBER-LIKE RESIN Flexible 3D Printer Photopolymer

Technical Data Sheet Disclaimer

Limitations, Responsibilities, and Legal Considerations

This Technical Data Sheet (hereinafter referred to as the "TDS") is provided by Monocure 3D Pty Ltd, a company duly incorporated and existing under the laws of Australia (hereinafter referred to as "Monocure 3D" or the "Company"). The information, data, and specifications set forth in this TDS pertain to the Monocure 3D products and materials (hereinafter referred to as the "Products").

The Company endeavours to ensure that the information contained herein is accurate, reliable, and up-to-date as of the date of publication. However, Monocure 3D disclaims all warranties, whether express, implied, or statutory, including, but not limited to, warranties of merchantability, fitness for a particular purpose, non-infringement of intellectual property rights, and any other warranties that may arise from the course of dealing, usage, or trade practice.

This TDS is intended solely for informational purposes and should not be construed as legal or other professional advice. The use or reliance upon the information contained herein is at the user's own risk. Monocure 3D shall not be held liable for any damages, losses, or expenses arising out of, or in connection with, the use of or reliance on the information in this TDS.

It is the user's responsibility to determine the suitability of the Products for their intended application, to comply with all applicable laws, regulations, and standards, and to take appropriate safety precautions in handling, using, and disposing of the Products.

This TDS may be subject to change at the Company's sole discretion without notice. Users should periodically consult Monocure 3D's website or contact the Company directly to obtain the most current version of the TDS. Monocure 3D reserves the right to modify, alter, or discontinue the Products or any specifications or information set forth herein without prior notice or liability.

Nothing contained in this TDS shall be deemed to create, or be construed as creating, any agency, partnership, or other relationship between Monocure 3D and the user or any third party.

This Disclaimer and any disputes or claims arising out of, or in connection with, the TDS or the Products shall be governed by and construed in accordance with the laws of common law, without regard to its conflict of law provisions. Any disputes or claims shall be subject to the exclusive jurisdiction of the competent courts of Australia.

By using or relying upon the information in this TDS, the user acknowledges that they have read, understood, and agree to be bound by the terms and conditions set forth in this Disclaimer.

